


INSTALLATION MANUAL FLEXFIT

Profiles – Carriers – Rubber Stops





	FlexFit 1537		FlexFit 1529		Rubber Stop 1537	Rubber Stop 1529
Carrier	3 wheel	5 wheel	3 wheel	5 wheel		
Article number	205S01	205S02	205S05	205806	_	-
Length	92 mm	158 mm	92 mm	158 mm	205S118	205S128
Weight	0.11 kg	0.18 kg	0.09 kg	0.14 kg	30 mm	30 mm
Load capacity	Radial 800N	Radial 1150N	Radial 425N	Radial 650N	0,04 kg	0,03 kg
Material	Stainless steel*	Stainless steel*	Stainless steel*	Stainless steel*	25J 10x	25J 10x
Fixation (threaded hole at pitch 33 mm)	2x M5	4x M5	2x M5	4x M5	Stainless steel*	Stainless steel*
Profile	Galvanised**	Stainless steel	Galvanised**	Stainless steel	<u>2xM5</u>	2xM5
Article number	205S03	205S098	205S07	205S108		
Length	2394 mm	3994 mm	2394 mm	3994 mm		
Weight	0.76 kg/m	0.75 kg/m	0.5 kg/m	0.48 kg/m		
Fixation (fixing recommendation DIN 7991)	M5 countersunk at pitch 80 mm		M5 countersunk at pitch 80 mm			
Profile and Carrier						
Total width	37 mm		29 mm		radial	
Total thickness	15 mm		15 mm			
Travel	Minimum 80 mm		Minimum 80 mm			10,10
Service life	60.000 cycles (60 km at max load capacity)		60.000 cycles (60 km at max load capacity)		1	
Tube of 20g lubricant						
Article number	16901223		16901223			

* AISI 304

** Steel: up to 96 hours before zinc corrosion


FLEXFIT INSTALLATION MANUAL -2





FLEXFIT INSTALLATION MANUAL






FLEXFIT INSTALLATION MANUAL -









FLEXFIT INSTALLATION MANUAL -5





FLEXFIT INSTALLATION MANUAL








INSTALLATION

FLEXFIT INSTALLATION MANUAL

1. Optimal cutting length

For stainless steel profile: use dedicated tools to prevent corrosion



2. Cleaning of profile






3. Lubricate profile




Rollers are sealed and lubricated for life: no lubrication or maintenance needed. Lubrication of profile-carrier contact is critical for high service life and load capacity. Recommended: TRI lubrication, art no 16901223 (tube 20 gram)

Cassida GTX2 (Registered by NSF Class H1, for incidental food contact) Please act according to the recommendations in the Material Safety Data Sheet of the used grease.

Clean profile each 60.000 cycles and renew lubrication for longer lifetime







FLEXFIT INSTALLATION MANUAL _ 10 _



Installation Flexfit Rubber Stop:

This Rubber Stop is developed for misuse situations and can absorb an energy of 25 Joules for 10 times. It's not developed as a stop in the rail for 100.000 cycles.

